

## Flash Coving

**TECHNICAL SUPPORT 800.345.6202**

- **First put your cove stick to support**



- **Fix the Cap Stick at the height desired (usually 6 inches)**



➤ **Trim to desired height**



➤ **Fit into position**



➤ **Outside corner**



➤ **Weld**



➤ **Once trimmed**



➤ **Internal corner**



For more information about Expanko visit: [www.expanko.com](http://www.expanko.com) or call 800.345.6202