

FLOAT FRAME

BRACKETS

Available through

CaraGreen

Healthy Building Materials

www.caragreen.com • 919.929.3009

info@caragreen.com

LOW PROFILE BRACKET | INSTALL GUIDE



1. Select the Low Profile Bracket size needed using the dimensional drawings provided



2. We recommend a maximum bracket spacing of 32" on center based on standard countertop materials



3. Mount each Low Profile Bracket using a zinc 5/16" x 1-3/4" lag screw in the top hole



4. Tighten zinc 5/16" x 1-3/4" lag screws



5. Adjust and level Low Profile Bracket to be in plane and level



6. Permanently fasten the Low Profile Bracket to the studs using zinc 5/16" x 1-3/4" lag screws in the bottom holes



7. Use zinc 5/16" x 1 3/4" lag screws through the remaining holes in the side flanges



8. Secure countertop surfacing to brackets



9. Finish Island and paint as needed

FLOAT FRAME BRACKETS

LOW PROFILE BRACKET | GUÍA DE INSTALACIÓN

Available through

CaraGreen

Healthy Building Materials

www.caragreen.com • 919.929.3009

info@caragreen.com



1. Elija el tamaño preciso de Low Profile Bracket con los dibujos dimensional provistos



2. Recomendamos un máximo de espacio entre los soportes de 32" en centre, con respecto a las normas para los materiales convencionales



3. Monte cada Low Profile Bracket con un tornillo de cabeza cuadrada en el agujero mas alto



4. Refuerce los tornillos



5. Ajuste y nivele el Low Profile Bracket hasta está llano



6. Permanentemente ate el Low Profile Bracket a los broches con los tornillos de cabeza cuadrada en los agujeros abajos



7. Use los tornillos de cabeza cuadrada por los agujeros restantes en las pestañas laterales



8. Abroche la encimera o el revestimiento a los soportes



9. Termine la isla y pinte como necesite